



OPT.QCSPD

Optima Quick Change Surface Preparation Discs

optima

Technical Data Sheet

PRODUCT DESCRIPTION

The Optima Quick Change Surface Preparation Discs are designed for light sanding, cleaning of metal parts and welds in tight and contoured surfaces. Impregnated nylon fibre netting provides consistent even sanding minimising clogging, tearing and heat build.

INSTRUCTIONS FOR USE

- Always wear the relevant PPE safety equipment including gloves, grinding apron and safety glasses.
- Use with the Optima Quick Change Mandrel
- Ensure the Quick Change Surface Preparation Disc is securely tightened to the Quick Change Optima Mandrel
- To lock in to place, simply hand tighten clockwise
- For use on air or electric die grinder
- Apply light pressure to work surface, allowing the abrasives to cut the surface to give an even finish
- To avoid damaging the surface, do not apply too much pressure

PRODUCT HIGHLIGHTS

- Strong nylon fibre weave is highly resistant to tearing and provides a long product life
- Tool free disc changing for fast and convenient use
- Impregnated grain giving consistent and smooth finish to all metal surfaces
- 50mm size is ideal for light sanding and preparation of awkward areas
- Quick change adaptor for easy change of product

PRODUCT DETAILS

Size:	50mm
Adaptor:	Optima Quick change adaptor with 6mm spindle

TECHNICAL SPECIFICATIONS

Bonding	Impregnated Nylon weave with resin bond
Colour	Various
Backing	Nylon fibre net backing
Grit Range	Extra fine, fine, medium, coarse, extra coarse

DISCLAIMER

All statements, technical information and recommendations are based on tests we believe to be reliable but the accuracy or completeness thereof is not guaranteed. Please ensure before using our product that it is suitable for your intended use. All questions of reliability relating to this product are governed by the Terms of Sale subject, where applicable, to the prevailing law.

