



OPT.CQCRSD

optima

# Optima Ceramic Quick Change Strip Disc

## Technical Data Sheet

### PRODUCT DESCRIPTION

The Optima Ceramic Quick Change Strip Disc is designed for preparation of flat and contoured metal surfaces. Including sanding old paint, rust removal and descaling weld burrs. The open structure is reduced to minimise heat build-up and clogging to the work surface. The Quick Change adaptor allows for fast convenient switching of products during use.

### INSTRUCTIONS FOR USE

- Always wear the relevant PPE safety equipment including gloves, grinding apron and safety glasses
- Use with the Optima Quick Change Mandrel
- Ensure the Quick Change strip disc is securely tightened to the Quick Change Optima Mandrel
- For use on air or electric die grinder
- Apply light pressure to work surface, allowing the abrasives to cut the surface to give an even finish
- To avoid damaging the surface, do not apply too much pressure

### PRODUCT HIGHLIGHTS

- Non-clogging for extended product life
- Ideal for fast surface preparation of metal
- Minimal risk of marking the panel
- High strength for fast removal of rust, sealers and paints
- No heat build up
- Quick change adaptor for change of product

### PRODUCT DETAILS

Size: 100mm

Adaptor: Optima Quick change adaptor with 6mm spindle

### TECHNICAL SPECIFICATIONS

Construction – Nylon Web

Grain – Ceramic

Colour – Orange

### DISCLAIMER

All statements, technical information and recommendations are based on tests we believe to be reliable but the accuracy or completeness thereof is not guaranteed. Please ensure before using our product that it is suitable for your intended use. All questions of reliability relating to this product are governed by the Terms of Sale subject, where applicable, to the prevailing law.

**Optima Products**, Newberry House, Michigan Drive, Tongwell,  
Milton Keynes, Buckinghamshire, MK15 8HQ  
**Tel:** 01908 611117 **Email:** [Optimaproducts@LKQCoatings.com](mailto:Optimaproducts@LKQCoatings.com)

