



OPT.CRSD

optima

Optima Ceramic Strip Disc

Technical Data Sheet

PRODUCT DESCRIPTION

The Optima Ceramic Strip Disc is designed for preparation of flat and contoured metal surfaces. Including sanding old paint, rust removal and descaling weld burrs. The open structure is reduced to minimise heat build-up and clogging to the work surface.

INSTRUCTIONS FOR USE

- Always wear the relevant PPE safety equipment including gloves, grinding apron and safety glasses
- Always use angle grinder with safety guard correctly positioned
- Ensure the strip disc is securely tightened to the angle grinder in line with the angle grinder manufacturers recommendation
- Always use the angle grinder with 2 hands
- Apply light pressure to work surface, allowing the abrasives to cut the surface to give an even finish
- To avoid damaging the surface, do not apply too much pressure

PRODUCT HIGHLIGHTS

- Non-clogging for extended product life
- Ideal for fast surface preparation of metal
- Minimal risk of marking the panel
- High strength for fast removal of rust, sealers and paints
- No heat build up

PRODUCT DETAILS

Size: 115mm

TECHNICAL SPECIFICATIONS

Construction – Nylon Web

Grain – Ceramic

Colour – Orange

DISCLAIMER

All statements, technical information and recommendations are based on tests we believe to be reliable but the accuracy or completeness thereof is not guaranteed. Please ensure before using our product that it is suitable for your intended use. All questions of reliability relating to this product are governed by the Terms of Sale subject, where applicable, to the prevailing law.

Optima Products, Newberry House, Michigan Drive, Tongwell,
Milton Keynes, Buckinghamshire, MK15 8HQ
Tel: 01908 611117 **Email:** Optimaproducts@LKQCoatings.com

